

## DAMPER ACTUATORS, 2-, 3-POINT AND PROPORTIONAL CONTROL (2 Nm)

DAK, DMK

#### **FUNCTION**

2- and 3-point or modulating 2...10 Vdc damper control.

#### **APPLICATIONS**

Designed for applications with small dampers (0.5  $\mbox{m}^{2}\mbox{)}~$  of ventilation and air handling units.

#### **FEATURES**

- universal adapter for easy direct mounting
- shaft dimension Ø 6...16 mm / 5...11 mm square
- 40 mm minimum shaft length
- anti-rotation bracket
- manual override by push button when required
- selectable direction of rotation
- adjustable angle of rotation, mechanical end stops
- 1 adjustable SPDT auxiliary switches on request

TYPE	POWER SUPPLY	SIGNAL CONTROL	
DAK24	24 Vac/dc	2-, 3-point	
DAK24S	24 Vac/dc	2-, 3-point	
DAK230	230 Vac	2-, 3-point	
DAK230S	230 Vac	2-, 3-point	
DMK24	24 Vac/dc	210 Vdc	

S  $\,$  models with 1 fixed auxiliary switch positioned on 10 $^{\circ}$ 


Actuator		DAK24	DAK230	DMK24
Damper area (*)	m²	0.5	0.5	0.5
Torque	Nm	2	2	2
Power supply		24 Vac/Vdc	230 Vac	24 Vac/Vdc
Frequency	Hz	5060	5060	5060
Power consumption				
W		2.0	1.5	2.5
VA	3.0	1.5	4.5	
Stroke time	S	3545	3545	4555
Weight	g	600	600	600
Control signal		2-, 3-point	2-, 3-point	210 Vdc
Aux. switch rating (only DAKS)		1 x SPDT 5 (2.5) A / AC 250 V	1 x SPDT 5 (2.5) A / AC 250 V	-
Rotation angle:		95°	95°	95°
Protection class		III	II	III
Degree of protection		IP54	IP54	IP54
Room temperature		-30+50°C	-30+50°C	-30+50°C
Room humidity		595% r.h.	595% r.h.	595% r.h.
Noise level		max 45 dB	max 45 dB	max 45 dB
Standards		CE	CE	CE


<sup>(\*)</sup> the indication of the damper area is not significant, the data that must be taken into account is the value of the torque in Nm.




### DAK, DMK

# DAMPER ACTUATORS, 2-, 3-POINT AND PROPORTIONAL CONTROL (2 Nm)








(\*) Refer to the cable numbering


#### Direction of rotation setting

The direction of rotation can be changed by moving the switch to the position  $\boldsymbol{L}$  or  $\boldsymbol{R}.$ 



#### Limitation of rotation angle


- 1. Loosen the screw of the mechanical limiter
- 2. Move the limiter to the appropriate position
- 3. Tighten the screw




# DAMPER ACTUATORS, 2-, 3-POINT AND PROPORTIONAL CONTROL (2 Nm)

## DAK, DMK

### INSTALLATION





### DIMENSIONS (mm)

